



# USAGE INSTRUCTIONS

## 1. Surface Preparation

- Clean area thoroughly, should be dirt and moisture free.
- Buff with 36–80 grit to expose fresh rubber.
- Remove all dust with vacuum or lint-free cloth.

## 2. Application

- Shake well before use.
- Pour the cement into a clean wide-mouth container.
- Apply a thin, even layer only on the buffed area using a clean brush.
- Do not apply cement on dirty/unbuffed surfaces.
- **Never dip the brush directly into the original container.**



# USAGE INSTRUCTIONS

## 3. Drying Time

- Wait until tacky (approx. 4–5 min, drying depends on the weather condition).
- Do not apply patch while it's wet.

## 4. Patch/Plug Placement and Stitching

- Position patch over tacky area.
- Press from centre to outward to remove air.
- Use a stitch roller for firm pressure in all directions from centre to outwards. This is to ensure that there is no air trapped in between the patch and Tire.

## 5. Curing

- Cold or hot cure depending on patch type.
- Allow proper curing time before inflating.

## **?** **STORAGE**

- Store below 25°C (77°F) in a cool, dry area.
- Keep sealed & away from sunlight, heat, and ignition sources.
- Shelf life: 24 months from manufacturing date, when unopened and well stored.
- Keep container tightly sealed to prevent evaporation.



## **WARNING / SAFETY**

- Flammable – Keep away from sparks & open flames. (for additional safety use appropriate fire extinguishers (Foam, Dry Chemical, or CO<sub>2</sub>).
- Use in a well-ventilated area.
- Wear protective gloves and goggles; avoid skin/eye contact. **(If contact with eyes, rinse thoroughly with water. Seek medical help if irritation persists.)**
- Do not inhale – use mask if necessary. **(If inhaled: Move to fresh air immediately)**
- Keep away from children.
- Dispose of empty containers safely as per local regulations.
- For professional use only.